## **Child Seats & Suggested Products**

Before choosing any of our vehicle harnesses, please check that the child is using the correct child car seat.

The law requires all children travelling in cars to use the <u>correct child restraint</u> until they are either 135 cm in height or the age of 12 (which ever they reach first). After this they must use an adult seat belt.

There are five main weight groups for child car seats - use this table to work out which seat your child should be using:-

Seat Group	Type of Child Car Seat	Weight Range	Approx. Age Range	Suggested Product *
Group 0 and 0+	Reward-facing Baby Seat with 5-point harness	0-13kg	Birth - 15 mths	Talk to ROSPA Tel: 0121 248 2000
Group 1	Forward- facing Child Seat with 5-point harness	9-18kg	9mths - 4 yrs	5 Point Plus for children over 15 months
Group 2	Booster Seat with Backrest but no 5-point Harness	15-25kg	4 - 6 yrs	Model 28
Group 3	Booster Cushion (with no backrest)	22-36kg	6 - 11 yrs	Any of our Vehicle Range can be used with a booster cushion
Group 1-2-3	Combines Group 1, 2 & 3	9-36kg	9mths - 11 yrs	5 Point Plus for children 15 mths to 4 yrs, Model 28 once 5 Point harness has been removed.

<sup>\*</sup> For further information on the most suitable harness please contact us on 01253 852298. For children under 4 please also seek advice from ROSPA - 0121 248 2000.

NB. Some child seats are capable of being converted as the child grows and, therefore, fit into more than one group or stage (i.e. Evolva 1-2-3). In this case, please refer to the Manufacturers User Instructions to determine when to remove the 5 point harness & use it as a Group 2 child seat. The guidelines advise that you try to keep your child in the lower-group child car seat for as long as you can - but make sure you don't leave it until your child is over the car seat's weight limit before changing.

Your child will have outgrown a Group 1, 2 or 3 child car seat if his or her eyes are level with the top of the seat.